

## HOOKING UP A FILTER PUMP *to your iPool or Therapy Pool*

### Step 1

Take one of your filter pump hoses, and attach it to the gray size converter (for filter pumps 1500 gph and above).

Connect this filter pump hose with the gray converter to the pool inlet port as shown to the right.



Pool Outlet Connection



Filter Pump Inlet

### Step 2

Attach the other end of your filter pump hose to the filter pump outlet port. For filter pumps 1500 and above it is located below the filter cartridge.



Filter Pump Connection



Filter Pump Outlet

### Step 3

From the filter pump outlet attach final filter pump hose to pool inlet.



Filter Pump Connection